


- Onderdelen -
- Spare parts -
- Pièces de rechange -
- Ersatzteile -



<b>No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Quantity</b>
1	Y471147HD-V2 - 1	Main Stand weldment	1
2	Y471147HD-V2 - 2	left clamp arm weldment	1
3	Y471147HD-V2 - 3	Right clamp arm weldment	1
4	Y471147HD-V2 - 4	Axle Weldment	1
5	Y471147HD-V2 - 5	PU foam wheel 10"	2
6	Y471147HD-V2 - 6	Tension Spring	2
7	Y471147HD-V2 - 7	spacer spool	6
8	Y471147HD-V2 - 8	Axle cap	2
9	Y471147HD-V2 - 9	Hex bolt M8*25	6
10	Y471147HD-10 - 10	Flat washer M10	12
11	Y471147HD-V2 - 11	Hexagonal nut M8-1.25	8
12	Y471147HD-V2 - 12	Nylon Plug M8	2
13	Y471147HD-V2 - 14	Compress spring	2
14	Y471147HD-V2 - 15	washer with thread	2
15	Y471147HD-V2 - 16	Hex bolt M8*45	2
16	Y471147HD-V2 - 17	Hex bolt M6*60	2
17	Y471147HD-V2 - 18	Flat washer M6	2
18	Y471147HD-V2 - 19	Nylon roller	2
19	Y471147HD-V2 - 20	Handle grip	2
20	Y471147HD-V2 - 21	end cap for frame	2
21	Y471147HD-V2 - 22	Smart Push Rod	1
22	Y471147HD-V2 - 23	Connection	2
23	Y471147HD-V2 - 24	Push Rod's Support	1
24	Y471147HD-V2 - 25	Hex bolts M8-1.25*45mm	2
25	Y471147HD-V2 - 26	Hex bolts M8-1.25*20mm	8
26	Y471147HD-V2 - 27	Main Spring	1
27	Y471147HD-V2 - 28	Flange Nylon Hex Nuts M8-1.25	10